

Programming codes (Firmware version W21-6.0)

 00381	 00380
Expand UPC-E to UPC-A	Unexpanded UPC-E to UPC-A
 00441	 00440
Add UPC-E check digit	Remove UPC-E check digit
 00430	 00431
Add UPC-E lead digit	Remove UPC-E lead digit
 00421	 00420
Add UPC-A check digit	Remove UPC-A check digit
 00400	 00401
Add UPC-A lead digit	Remove UPC-A lead digit